

# DK02A-190VDC, DK02A-24VDC ELEKTRİK BAĞLANTI ŞEMASI / ELECTRIC WIRING DIAGRAM

-DK02A Kilit Kontakları Bağlantısı  
-DK02A Interlock Contact Wiring Diagram

TOPRAK / GROUND


KAHVERENGİ / BROWN

KAHVERENGİ / BROWN


SİYAH / BLACK

SİYAH / BLACK

**PANO**



-DK02A Selenoid Bobin Bağlantısı  
-DK02A Selenoid Coil Wiring Diagram



## BAKIM TALİMATI

- 1- Aylık rutin asansör bakımlarında, toz ve pisiği üzerine sabitleyen katı yağlar yerine sıvı yağlar kullanılmalıdır.
- 2- Periyodik kontrollerde kilit üzerindeki pislik ve tozları temizleyiniz.
- 3- Etiket talimatlarına uyunuz.
- 4- Kilidi kapı kasasından sökerken asansörü kapatınız.
- 5- Kontakların üzerindeki tortu ve pislikleri temizleyerek iletkenliğini kontrol ediniz

## MAINTENANCE INSTRUCTIONS

- 1- Must use fine industrial oils instead of hard industrial oils meanwhile montly maintenance.
- 2- Be in the clear of dust and dirt meanwhile periodic review.
- 3- Comply with the instructions on label.
- 4- While disassemble interlock on door, please shot down the elevator.
- 5- Be in the clear of dust and dirt on plug contacts after then check conduction currents on plug contacts.



[www.deltatek.com.tr](http://www.deltatek.com.tr)



**DELTA TEK & LİFSOR**  
High Quality Elevator Components